



OPERATOR MANUAL

S-103

PN: 1800002

Revision 12/05/2022



REGISTER YOUR HOIST SYSTEM

Improve your Switch-N-Go® experience by taking a few minutes to register your hoist system.

To register your hoist system, you will need the following information:

- Hoist System Model Name (Ex. XX-XXXX-XXX-XXX)
- Serial Number (found on the driver's side of the hoist system)
- Proof of Purchase (invoice or bill of sale)
- Install Company Information

You can find more about this information on page 15, UNDERSTANDING YOUR HOIST SYSTEM.

Once all required steps are completed, select REGISTER at the bottom of the form to receive confirmation of your hoist system registration.



SCAN THIS CODE

to visit owner's portal or visit us at switchngo.com/support-ops



Table of Contents

| | |
|--|-----------|
| General Warnings | 6 |
| Warning Indicators | 6 |
| Operator Precautions | 7 |
| Winch Precautions | 7 |
| Hoist System Warnings | 9 |
| Winch Warnings | 11 |
| Safety Decals | 12 |
| Hoist System Diagram | 13 |
| Common Parts Diagram | 13 |
| Common Truck Body Diagrams | 14 |
| Switch-N-Go® Hoist System | 15 |
| Understanding your Switch-N-Go® System | 15 |
| E-SERIES Requirements | 18 |
| Electric Winch Ratings | 18 |
| Adjusting Hydraulic Pressure | 18 |
| H-SERIES Requirements | 19 |
| Hydraulic Winch Rating | 19 |
| Adjusting Hydraulic Pressure | 20 |
| Hoist System Operation | 22 |
| Operating Precautions | 22 |
| Operating the Control Pendant | 23 |
| Loading a Truck Body | 25 |
| Unloading a Truck Body | 29 |
| Dumping Cargo | 32 |
| Attaching the Cable Hook | 33 |
| Removing the Cable Hook | 33 |

| | |
|---------------------------------------|-----------|
| Operational Weight Capacities | 34 |
| Calculating the Maximum Cargo Weight | 34 |
| Calculating the Actual Cargo Weight | 35 |
| Density of Materials | 36 |
| Maintenance & Repairs | 38 |
| Replacement Parts | 38 |
| E-SERIES Hoist System Parts | 38 |
| H-SERIES Hoist System Parts | 40 |
| Body Prop Rod Warnings & Use | 42 |
| Operate the Body Prop Rod | 43 |
| System Maintenance | 44 |
| Winch Cable Replacement | 46 |
| Winch Cable Installation | 46 |
| Hoist System Hydraulic Fluid Change | 48 |
| Lubricating the Hoist System & Bodies | 50 |
| Grease Fitting Diagram | 50 |
| Lubricating the Winch Cable | 51 |
| System Test & Pre-Operation Checklist | 52 |
| Appendix | 54 |
| Torque Table | 54 |
| Control pendant Pin-out Diagram | 54 |
| System Diagram {E-SERIES} | 56 |
| System Diagram {H-SERIES} | 57 |

KNOW YOUR TRUCK. Practice operating your system safely. Keep your truck in safe operating condition with the correct and proper maintenance.

Do not consume/use drugs or alcohol before or during operating/driving of machinery



Always maintain a safe operating distance to vehicles, structures or surroundings



WARNING INDICATORS

Safety decals and instructional procedures are placed in this manual, on the hoist system, and truck bodies to provide safe operating precaution or procedures to identify potential hazards. Misuse or failure to operate the system as instructed can lead to damage, serious injury or death.

⚠ DANGER

⚠ DANGER

Indicates a hazardous situation that, if not avoided, could result in serious injury or even death

⚠ WARNING

⚠ WARNING

Indicates to hazardous situation that, if not avoided, could result in minor to severe injury

⚠ CAUTION

⚠ CAUTION

Indicates a hazardous situation that, if not avoided, could result in minor to moderate injury

⚠ NOTICE

⚠ NOTICE

Indicates information considered important, but not hazard-related



OPERATOR PRECAUTIONS

You must be trained to operate a Switch-N-Go® hoist system. This operator's manual is not a training manual. It is a guide to help trained and authorized operators safely operate a Switch-N-Go® hoist system by illustrating and emphasizing the correct techniques. This manual cannot cover every possible situation that may result in an accident and the operator must watch for potential hazards during operation of the hoist system.

This product is built for hard use, but not excessive abuse. It is only as safe and efficient as the operator and person maintaining it. Do not use it for unintended purposes. Do not make any repairs unless you have been trained in safe vehicle and Switch-N-Go® hoist system procedures and/or are authorized by your vehicle/system owner. Do not operate a damaged or malfunctioning vehicle or hoist system.

WINCH PRECAUTIONS

The Switch-N-Go® electric system is designed for up to 6 fully loaded draws per day. A fully loaded winch draw is equal to the rating of the winch. If you are loading a lesser weight, the system will be able to pull more than six loads per day with proper cool-down periods in between. Overworking the winch will cause the electric winch motor to overheat, resulting in permanent damage. Let the winch motor cool down before resuming operation. The Switch-N-Go® hydraulic system is designed for unlimited number of winch draws and lifts per day. Before you start operating the winch or hoist system, be sure you understand all the procedures.

- Before initial use of your winch, test the system is working properly. **MAKE SURE TO KEEP HANDS AWAY FROM WINCH CABLE AND HOOK WHILE WINCH TESTING.**
- Never touch the winch cable or hook while it is in tension or under load. Even at rest, the winch cable may have tension.
- Always wear heavy-duty leather gloves when handling the winch cable as to protect hands from contact with the lubricated wire cable.
- Never handle the winch cable while another individual is operating the controls of the system or vehicle.
- Always stand clear of the winch cable and or loaded body during operation of the winch, as a cable may pull loose or break while under load this can cause damage or injury. Always be mindful of your own safety and the safety of others.



- Always be certain the cable that you intend to use is capable of withstanding the load.
- Operate the winch with common sense and never wrap the cable around an object or a person and hook it back to the winch cable as this will cause damage or injury.
- The winch must maintain a minimum of 5 wraps on the drum in the direction indicated on the winch. With fewer wraps, the winch cable could break loose from the drum under heavy load.
- The spool direction of the winch cable can accidentally be reversed by running the winch cable all the way out and re spooling in the opposite direction causing the winch to spool "IN" when the "OUT" button is pressed.
- Never exceed the rated capacities of the system's winch or vehicle's (GVWR) when lifting a loaded body.
- Always load a body in-line with the hoist system to minimize the coil buildup of winch cable on only one end of the spooling drum.
- Operate the winch controls smoothly and reduce any slack to avoid shock loads which can momentarily exceed the winch and winch cable rating.
- The life of the winch cable is directly related to the care it receives. New winch cables or replacement winch cables **MUST BE STRETCHED AND RESPOOLED UNDER LOAD** before operating the winch. Failure to do this will result in premature winch cable damage.
- To prepare the winch for heavy loads, un-spool the winch cable and tightly level wind winch cable onto the drum. This will minimize winch cable damage, such as mashing and kinking, caused from top layers pulling down into bottom layers when short pulls are made. The greatest loading power is available at the first layer on the drum, decreasing with each successive coil.
- Always inspect winch cable for mashed, pinched, or frayed areas prior to loading a body. This greatly reduces the original tensile strength of the winch cable and it should be replaced if there are any cable issues found.



- When spooling "IN" the winch cable, be sure to distribute the winch cable evenly and tightly onto the drum. This prevents the top layers of winch cable from being drawn into the bottom layers of the winch cable and creating a bind. If the winch cable binds on the drum, the winch and/or winch cable may be damaged. A bound winch cable will reel OUT only a short distance and then reel back IN even though the "OUT" button is being pressed. A bound winch cable must be corrected before using the winch. Should the winch cable become bound, connect the hook to a load, then by alternating the winch "IN" then "OUT", the winch cable will usually work itself free. **DO NOT PUT YOUR HANDS ANYWHERE NEAR THE WINCH CABLE WHEN WORKING A BIND FREE.**
- Before using the electric winch, inspect the control pendant cord for cracks, pinched spots, frayed wires, or loose connections. A damaged or shorted cord could cause the winch to operate incorrectly.

HOIST SYSTEM WARNINGS

DANGER

Bouncing or jerking of the hoist system is to be avoided as it may result in component failure, injury or death.

DANGER

Do not raise or drive a raised body against another object. Doing so could result in equipment or property damage, injury or death.

WARNING

The hoist system cylinder shall not serve as a structural member to absorb side loads; the cylinder shall only provide a lifting force along the axis of the cylinder. No force acting radially to the cylinder should be applied to the cylinder as damage could result.

⚠ WARNING

Do not operate hoist system until bystanders are free and clear of the hoist system and body.

⚠ WARNING

Never exceed the Gross Vehicle Weight Rating (GVWR) or the Gross Axle Weight Rating (GAWR) of your vehicle. Overloading a truck can cause component damage, injury or death.

⚠ CAUTION

Unlatch tailgate prior to elevating a loaded dump body as excessive forces on the rear of the dump body may result in component failure.

⚠ CAUTION

Never operate the hoist system on unlevel or soft terrain as this may cause component damage and/or the vehicle to rollover.

⚠ CAUTION

Relieve pressure before disconnecting hydraulic lines. Tighten all connections before applying hydraulic pressure. Protect hands, eyes, and body from high-pressure fluid leaks. Wear protective eyewear and gloves when accessing the hydraulic system or searching for leaks.

⚠ WARNING

Never place any body part between the hoist system scissor action and hoist system frame unless the body prop rod is engaged to hold up the hoist system. Use the body prop rod to hold the hoist system upright when certain kinds of equipment maintenance are to be performed.

⚠ WARNING

DO NOT CHANGE THE CONTROL PENDANT CORD LENGTH. The length of the cord has been carefully determined to decrease the chance of the operator injury during the loading and unloading process.

⚠ WARNING

Be AWARE of your surroundings when operating the hoist system/winch from inside the truck cab. It is recommended that you operate the hoist system alongside of the vehicle to observe the loading/unloading process.

WINCH WARNINGS**⚠ CAUTION**

Do not exceed the line pull rating shown on the winch identification label. Exceeding the winch pull rating will abuse the motor and cause failure. Do not exceed the maximum rating of the winch cable being used.

⚠ CAUTION

Do not exceed rated duty cycle of electric winch when changing bodies. The electric winches are rated for intermittent duty operation only.

⚠ CAUTION

Disconnect the control pendant when not in use as this prevents accidental activation of the hoist system or winch while driving.


⚠ WARNING

Shock loads result when the winch cable is spooled out before the body is ready to let gravity roll it off the Switch-N-Go® system. It is necessary to keep the cable tight at all times by first raising the hoist to the proper angle. Just one significant shock load with a heavy body can cause a winch failure.




SAFETY DECALS

Safety Decals only available as a complete kit and are available upon request through your local Switch-N-Go® Dealer.









HOIST SYSTEM DIAGRAM




COMMON PARTS DIAGRAM



COMMON TRUCK BODY DIAGRAMS

UNDERSTANDING YOUR SWITCH-N-GO® SYSTEM

Before installing or operating the Switch-N-Go® Hoist System, please review and understand the hoist system. Identify the serial/model identification tag, located on the driver's side of the Switch-N-Go® top hoist frame, near the front.



SERIAL NUMBER


This identification or serial number is unique to each model, manufacturing date, and sales order. This serial number is used for warranty claims and technical support.

MODEL NAME

The model name is based on the 4-part identification code shown on next page. This is not a unique identifier.

PART NUMBER

The part number helps identify your hoist system to our internal team and may be requested when contacting technical support.





E-SERIES
MODEL

Indicators —

11-4016-15E-10T

1

2

3

4



H-SERIES
MODEL

Indicators —

14-5020-18H-10T

1

2

3

4

Indicators on the example are provide below with brief descriptions of how to understand your hoist model name.



HOIST SYSTEM LENGTH

The Switch-N-Go® model length is unitized by foot increments. The length is less than the cab to end of frame (CEF) of the vehicle chassis ranging from 9' (108") up to 14' (168"). Systems that are shorter or longer are acceptable but require additional modifications or accessories. For additional information see your vehicle manufacturer's up-fit documents. The standard Switch-N-Go® hoist system has an 18" overhang.



SCISSOR HOIST SERIES

The scissor hoist system is built by Rugby™ for Switch-N-Go® hoist systems. The series can be identified by the 4-digit number in the model name: 4016, 4020, or 5020.



HOIST SYSTEM | E-SERIES

The Switch-N-Go® E-series (electric series) is an electric-over-hydraulic system that has a Warn electric winch and a hydraulic hoist system. This system is designed for up to 6 fully loaded draws per day. A fully loaded winch draw is equal to the rating of the winch, which is 15,000lbs. If you are loading a lesser weight, the system will be able to pull more than six loads per day. This system utilizes a hydraulic scissor hoist system, allowing for unlimited dumping. The Switch-N-Go® full electric operation system is equipped with a pre-wired electric Warn winch and a separate on-board electric-powered hydraulic hoist system. The E-series offers a winch capacity of 15,000 lbs. as indicated as by the 15 in the model name followed by an "E" for electric. This is ideal for GVWR vehicles between 13,500 lbs. - 26,000 lbs. The E-series is supplied with a 600-amp fuse, power, and ground wires in the E-series installation kit.

3



HOIST SYSTEM | H-SERIES

The Switch-N-Go® H-series (hydraulic series) is a full hydraulic system that has a Warn hydraulic winch and a hydraulic hoist system. This system is designed to handle an unlimited number of winch draws and dumps per day. This system utilizes a hydraulic pump, supplied by either a "live" drive-style power take-off (PTO) or an under-hood clutch pump for both the winch and the hoist system. The H-series offers two combined hydraulic-powered winch/hoist system capacities: 15,000 lbs. or 18,000 lbs. as indicated as by a 15 or 18 in the model name followed by an "H" for hydraulic. This is ideal for GVWR vehicles between 16,000 lbs. - 33,000 lbs. The H-series requires more components to be installed onto the truck including a hydraulic pump, reservoir, filter, and additional hoses. These components are not provided with the H-series installation kit.



HOIST SYSTEM | S-MODEL

The Switch-N-Go® S-model hoist system has a shorter 6" overhang for easier access to the hitch under the truck body. This is shown in the model name by an "S" following the winch type indicator.

4



HOIST CAPACITY

The dumping capacity of the hoist system differs from the pulling capacity of the winch. The last alpha-numeric indicator in the model name refers to the hoist system capacity. For example, 10T would indicate the hoist system is capable of dumping 10 tons.



E-SERIES REQUIREMENTS

The electric-over-hydraulic system does require components that are provided in the E-Series installation kit during hoist system installation. This system requires that one 600-amp ANL fuse and fuse holder be installed within the vehicle's engine compartment, within 18" of the battery.

Additional Vehicle Installation Components

- Alternator - A heavy duty alternator with a 150 AMP minimum capacity
- Batteries - Two deep cycle 750 CCA or greater batteries
- Fluid - 7.5-12 quarts of hydraulic oil equivalent to Grade 32 (such as ATF-Dextron II or Mobile DTE 13)

⚠ CAUTION

Make sure to test that the alternator and batteries are functioning properly and meet the system requirements as stated. Failure to meet the requirements may result in a weak or non-functioning system.

⚠ WARNING

The battery is capable of providing its unlimited current in the event of a short circuit. If a short circuit occurs, damage to the wiring system or a fire may result. Fuses provide the most reliable circuit protection. Failure to provide circuit protection may result in a fire or damage the vehicle. A 600-amp ANL fuse is provided in the electric installation kit. Install the fuse on the battery power supply cable, as close as possible to the battery.

ELECTRIC WINCH RATINGS

| Winch Reference | Maximum Body Weight | Instruction Manual | Maximum Loaded Body Pulls per Day | Winch Operation Cooldown Period |
|-----------------|---------------------|--------------------|-----------------------------------|---|
| 15E | 15,000 lbs. | Startup Guide | Up to 6 pulls | Approximately 1 hour between maximum loaded winch pulls |

ADJUSTING HYDRAULIC PRESSURE

The hydraulic system included with your Switch-N-Go® hoist system has been preset and tested at the factory. Modification to this system should not be needed and doing so may void the factory warranty. Contact your installer if adjustments to the hydraulic system are needed.



H-SERIES REQUIREMENTS

The full hydraulic system requires components that are provided in the H-Series installation kit during hoist system installation. This system requires that the 25 AMP blade-type fuse and fuse holder be installed within the vehicle engine compartment, preferably near the battery and the fuse box.

Additional Vehicle Installation Components

- Pump - A hydraulic pump either a Clutch Pump or "live drive" style Power Take Off (PTO) Pump: that is capable of producing 3000 PSI pressure at a flow rate of 12-15 GPM.
- Hoses - Hose that is flame resistant and rated for use of hydraulic oil with a minimum burst pressure of 3000 PSI. Need varying lengths of the hose in both 1/2" and 3/4" diameters.
- Tank - A 15-20 gallon tank rated for hydraulic oil use with a basket strainer in the filler tube.
- Filter - An inline hydraulic filter with an internal bypass is recommended
- Fluid - 18-23 gallons of hydraulic oil equivalent to Grade 32 (such as ATF-Dextron II or Mobile DTE 13)

⚠ DANGER

Connecting the hoist system to a hydraulic system with more pressure (psi) or flow (gpm) than is recommended by the hoist system manufacturer can lead to damage, serious injury or death.

HYDRAULIC WINCH RATING

| Winch Reference | Maximum Body Weight | Instruction Manual | Maximum Loaded Body Pulls per Day | Winch Operation Cooldown Period |
|-----------------|---------------------|--------------------|-----------------------------------|---------------------------------|
| 15H | 15,000 lbs. | Startup Guide | Unlimited pulls | N/A |
| 18H | 18,000 lbs. | Startup Guide | Unlimited pulls | N/A |



Failure to follow pressure and flow rate specifications below may result in lower speeds, less capacity, or premature system failure.

RUGBY HYDRAULIC PRESSURE SETTINGS

| Rugby SR Hoist Specifications | Maximum Hydraulic Flow Rate | Maximum Pressure for Raising Portion of Dump Cycle | Maximum Pressure for Lowering Portion of Dump Cycle |
|-------------------------------|-----------------------------|--|---|
| SR-4016 | 6 GPM | 3200 psi | 1000 psi |
| SR-4020 | 6 GPM | 3200 psi | 1000 psi |
| SR-5020 | 9 GPM | 3200 psi | 1000 psi |

WARN HYDRAULIC PRESSURE SETTINGS

| H-Series 15,000lbs Specifications | Maximum System Pressure | Pressure at Maximum Rated Load | Maximum Rated Input Flow |
|-------------------------------------|--|--------------------------------|--------------------------|
| Warn Hydraulic Winch Specifications | 2200psi | 2200 psi | 15 GPM |
| | 152 BAR | 152 BAR | 57 LPM |
| | Control Valve Type: 3-Position, 4-way, closed center, spring return (cylinder spool) | | |

| H-Series 18,000lbs Specifications | Maximum System Pressure | Pressure at Maximum Rated Load | Maximum Rated Input Flow |
|-------------------------------------|--|--------------------------------|--------------------------|
| Warn Hydraulic Winch Specifications | 2400psi | 1816 psi | 15 GPM |
| | 166 BAR | 125 BAR | 57 LPM |
| | Control Valve Type: 3-Position, 4-way, closed center, spring return (cylinder spool) | | |

ADJUSTING HYDRAULIC PRESSURE

The hydraulic system included with your Switch-N-Go® hoist system has been preset and tested at the factory. Modification to this system should not be needed and doing so may void the factory warranty. Contact your installer if adjustments to the hydraulic system are needed.



OPERATING PRECAUTIONS

Please read all instructions before proceeding. Failure to follow these instructions could damage the vehicle or cause injury or death.

⚠ WARNING

DO NOT OVER WORK THE WINCH. The electric winch can only operate for 3-5 minutes at its maximum load limit. Then, it must rest for approximately 1 hour before operating again.

⚠ WARNING

The hoist system must be lowered down before securing the cable to the hook stow point located at the rear mounting bracket. Failure to do so may result in major damage to the top frame and subframe of the hoist system and cause it to function improperly.

⚠ CAUTION


It may be necessary to let the truck drive under the load to minimize the stress on the winch when the terrain will not permit normal loading. The operator must be in the truck cab for this style of loading.

⚠ NOTICE


During freezing weather it is recommended that the body be placed on blocks so that it does not freeze to the ground. Pulling a body frozen to the ground can cause excess stress on the winch.




OPERATING THE CONTROL PENDANT




- Step 1—** Connect the control pendant to the in-cab pendant receptacle or to the outside pendant receptacle located on the driver's side of the hoist system's subframe.
- Step 2—** Refer to the diagrams below to learn the buttons functions.




[HOIST]
—
HOIST UP




[HOIST]
—
HOIST DOWN



[WINCH]
—
WINCH OUT



[WINCH]
—
WINCH IN





! WARNING

Before lifting any heavy load, review this loading precautions checklist:

- Check that the safety keeper on the winch cable hook is securely closed around the truck body load pin before dumping.
- Check that the winch is in working condition and will withstand the load of truck body and load during dumping.
- Check to be sure that no individual is behind the vehicle and truck body.
- Check that there is sufficient height clearance so that unloading is not obstructed by over-head obstacles.

! CAUTION


Ensure the vehicle is on a level and firm surface away from any overhead obstructions.

**SCAN THIS CODE**

to see an instructional video or visit us at switchngo.com/operate

LOADING A TRUCK BODY

- Step 1—** Back the vehicle until the yellow rear rollers are near the front uprights of the unloaded truck body and ensure the vehicle is in line with the truck body.







- Step 2—** Attach the cable hook to the load pin on the truck body. Ensure the safety keeper on the cable hook is securely closed. See Attaching the Cable Hook instructions on page 33 for more detail.
- Step 3—** Slowly pull your truck forward, putting slight tension on the cable.
- Step 4—** Connect the control pendant to a control receptacle located either inside the vehicle's cab or on the hoist system's subframe.
- Step 5—** Before putting the truck in neutral, ensure it is on level ground. Press the button marked winch "IN" while ensuring the winch cable is properly directed through the center V-roller. This will draw the truck closer to the body. The truck body's front uprights should be centered between the yellow rear rollers.
- Step 6—** Press the button marked hoist "UP" using the reference below as a guide:

| State of Truck Body | Initial Angle of Hoist |
|---------------------|------------------------|
| Empty / Unloaded | 25° - 30° |
| Full / Loaded | 50° - Full Height |


- a When loading with the operator outside the vehicle cab, make sure to ENGAGE THE VEHICLE'S PARKING BRAKE.
- b When loading with the operator inside the vehicle cab: DISENGAGE THE VEHICLE'S PARKING BRAKE AND PLACE THE VEHICLE IN NEUTRAL. This will allow the vehicle to drive under the loaded body as you pull the winch "IN".



- Step 7—** When the body's long sills (bottom rails) reach the yellow rear rollers, press the button marked hoist "DOWN" to nearly match the angle of the body's runner rails.




- Step 8—** Press the button marked winch "IN" until the truck body's rear rollers are off the ground.




⚠ DANGER

If the vehicle's front wheels lift off the ground at any time, This is an **OVERLOADED, UNSAFE CONDITION**. Unload the body and lighten the load, then restart the loading procedure.

- Step 9—** Press the button marked hoist "DOWN" until the top frame is about 10" above the subframe, as this will relieve the winch draw due to pulling the truck body against the force of gravity.



- Step 10—** Press the button marked winch "IN" at this lower angle until the truck body comes against the front stops. The winch stop switch will shut-off and halt winching the body inward.




- Step 11—** Press the button marked hoist "DOWN" to rest the top frame onto the subframe of the hoist system. This locks the front body lock to the subframe of the hoist system.

NOTE

Do not lower the hoist system down entirely before the winch cable is retracted all the way, otherwise the body will not be secured into the front body lock.

- Step 12—** Locate and insert the body lock safety pin into the hole on the driver-side hoist system's top frame near the front body lock.



- Step 13—** Disconnect control pendant from the control receptacle and safely stow away inside the cab.

⚠ WARNING

Before lifting any heavy load, review this loading precautions checklist:

- Check that the safety keeper on the winch cable hook is securely closed around the truck body load pin before dumping.
- Check that the winch is in working condition and will withstand the load of truck body and load during dumping.
- Check to be sure that no individual is behind the vehicle and truck body.
- Check that there is sufficient height clearance so that unloading is not obstructed by over-head obstacles.


⚠ CAUTION

Ensure the vehicle is on a level and firm surface away from any overhead obstructions.

UNLOADING A TRUCK BODY


Step 1— Position the vehicle's body ensuring there is enough space to unload the body and add 5 feet of working space behind the truck body once unloaded from the vehicle.

Step 2— Locate and remove the body lock safety pin from the hole on the driver-side hoist system's top frame near the front body lock.






- Step 3—** Connect the control pendant to a control receptacle located either inside the vehicle's cab or on the hoist system's subframe.
- Step 4—** Press the button marked hoist "UP" to approximately 35-45° angle.
- Step 5—** Press the button marked winch "OUT" to allow the body to roll downward off the hoist glide pads. The rear rollers of the truck body will touch the ground and continue to move backwards.




- a** Continue pressing the button until the front of the truck body has completely made contact with the ground.
- b** Once contact has been made with the ground, you can also slowly drive forward while winching out until the body is fully on the ground. Continue pulling forward about 3 more feet.

- Step 6—** Add slack in the winch cable by either backing the truck up slightly or continuing to press the button marked winch "OUT." Ensure to keep a minimum of 5 wraps of cable on the winch drum.



Step 7— Unhook the cable hook from the truck body and attach the hook at the hoist system's rear mounting bracket labeled Stow Hook Here.

Step 8— Press the button marked hoist "DOWN" to lower the hoist system all the way down.



Step 9— If needed, press the button marked winch cable "IN" while keeping slight tension on the cable with your hands to prevent the cable from dragging on the ground. Always wear protective gloves when handling the winch cable.

Step 10— Disconnect pendant controller from the control receptacle and safely stow away inside the cab.



DUMPING CARGO


! WARNING

Always look to make sure the area and immediate surroundings where you wish to dump are clear, both behind and overhead

Step 1— Ensure there are no over-head obstacles that can be hit by the rising hoist and loaded body.

! WARNING

The body lock safety pin must be in the front body lock at all times during the dumping procedure. Make sure the body lock safety pin is inserted into the body lock. This is to prevent the body from sliding while dumping.



- Step 2—** Disengage the tailgate latch and release any safety chains.
- Step 3—** Connect the control pendant to a control receptacle located either inside the vehicle's cab or on the hoist system's subframe.
- Step 4—** Press the button marked hoist "UP" to the desired angle (up to 50°) until material starts moving.
- Step 5—** If the load does not begin to fall from the body, slowly pull the vehicle forward to dislodge the load from the truck body. Watch for overhead obstacles!
- Step 6—** Once dumping is complete, press the button marked hoist "DOWN".
- Step 7—** Latch the tailgate shut and secure the safety chains.
- Step 8—** Disconnect pendant controller from the control receptacle and safely stow away inside the cab.

ATTACHING THE CABLE HOOK


⚠ NOTICE

Always wear heavy-duty leather gloves when handling the winch cable.

⚠ NOTICE

Always inspect winch cable for mashed, pinched, or frayed areas when operating the winch as this can severely reduce the strength of the winch cable. Replace the cable if necessary.

- Step 1—** After the truck is backed up and touching the body, the cable should be at the right length to reach the body. If a little more cable length is needed, press the button marked winch "OUT" while adding tension to the cable. Ensure there is still a minimum of 5 wraps on the winch drum.
- Step 2—** With the cable hook in hand, locate the load pin at the lower-middle of the truck body front end.
- Step 3—** Attach the cable hook to the load pin, ensuring the safety keeper is securely closed.




REMOVING THE CABLE HOOK

⚠ CAUTION

Never touch the winch cable or hook while it is under tension or loaded. The winch cable may have tension, even if at rest.

- Step 1—** After setting the body on the ground, and slowly pulling ahead while winching out, back the truck up 6"-12", creating slack (no tension) in the cable.
- Step 2—** Press inward on the safety keeper on the cable hook.
- Step 3—** Remove the cable hook from the body load pin.
- Step 4—** Hook the cable hook to one of the rear hold-down points located at the back of the hoist system.
- Step 5—** If the cable length is too long and is close or is contacting the ground, press the button marked winch cable "IN" while keeping slight tension on the cable with your hands. Some slack in the cable is acceptable. Always wear protective gloves when handling the winch cable.





Operational Weight Capacities

CALCULATING THE MAXIMUM CARGO WEIGHT

The legal maximum cargo weight is calculated by subtracting the “Total Unloaded Vehicle Weight” from the “Gross Vehicle Weight Rating”. The “Gross Vehicle Weight Rating” is listed on the tag located on the inside of the driver door. The “Total Unloaded Vehicle Weight” is calculated by finding the sum of the truck’s curb weight, occupants, truck body, the Switch-N-Go® hoist system and upfitted options. See below for EXAMPLES on how to calculate the Legal Maximum Cargo Weight.

! NOTICE

The calculations below are for example only. You will need to calculate your own values based on the truck, type of system, and size of body being used.

Total Unloaded Vehicle Weight

Total Unloaded Vehicle Weight = truck’s curb weight + occupants + body + hoist system

| Description | Weight in lbs |
|---|------------------|
| Truck curb weight | 7,250lbs |
| Occupants (2 persons weighing approximately 225lbs each) | 450lbs |
| Switch-N-Go® hoist system & 11 ft. dump body w/ rear bumper | 2,400lbs |
| Total Unloaded Vehicle Weight (TUVW) | 10,100lbs |

Legal Maximum Cargo Weight

Legal Maximum Cargo Weight = Gross Vehicle Weight Rating - Total Unloaded Vehicle Weight

| Description | Weight in lbs |
|--------------------------------------|-----------------|
| Gross Vehicle Weight Rating (GVWR) | 19,500lbs |
| Total Unloaded Vehicle Weight (TUVW) | 10,100lbs |
| Maximum Cargo Volume | 9,400lbs |

Maximum Cargo Volume



SCAN THIS CODE

to calculate your truck body maximum cargo volume or visit us at switchngo.com/volcalc



CALCULATING THE ACTUAL CARGO WEIGHT

The actual cargo weight is calculated by taking the vehicle's Maximum Cargo Volume and multiplying it by the approximate Material Density. (Reference chart on next page for typical material densities.) Compare this Actual Cargo Weight to the calculated Legal Maximum Cargo Weight to verify cargo loads.

Actual Cargo Weight

Actual Cargo Weight = Maximum Cargo Volume x Material Density

Determining Permitted Cargo Weight

Permitted Cargo Weight = Legal Maximum Cargo Weight - Actual Cargo Weight

| EXAMPLE 1 | |
|---|------------------------|
| Dump Body Maximum Cargo Volume | 2.99 yd ³ |
| Material Density of Sawdust (per chart) | 354lbs/yd ³ |
| Actual Cargo Weight (calculated) | 1058lbs |
| Legal Maximum Cargo Weight | 9,400lbs |
| Actual Cargo Weight | 1058 lbs. |
| Difference (LIGHTER than legal maximum) | 8,342 lbs. |

The actual cargo weight of loaded sawdust is lighter than the legal maximum cargo weight of a 11' dump body, with a difference of 8,342 lbs. This example vehicle cargo weight is legal to haul.

| EXAMPLE 2 | |
|---|----------------------------|
| Dump Body Maximum Cargo Volume | 2.99 yd ³ |
| Material Density of Large Solid Granite (per chart) | 4536 lbs/yd ³ |
| Actual Cargo Weight (calculated) | 13,563 lbs/yd ³ |
| Legal Maximum Cargo Weight | 9,400lbs |
| Actual Cargo Weight | 13,563lbs |
| Difference (HEAVIER than legal maximum) | -4,163lbs |

The actual cargo weight of loaded large limestone is heavier than the legal maximum cargo weight of a 11' dump body, with a difference of 4,163 lbs. This example vehicle cargo weight is NOT legal to haul.



DENSITY OF MATERIALS

Reference Only

| Material ¹ | (lbs/yd ³) | (kg/m ³) |
|------------------------------|------------------------|----------------------|
| Alfalfa | 432 | 256 |
| Apples | 1080 | 641 |
| Asbestos - shredded | 539 | 320 |
| Ashes - wet | 1230 | 730 |
| Ashes - dry | 961 | 570 |
| Asphalt, crushed | 1215 | 721 |
| Barley | 1027 | 609 |
| Beans | 973 | 577 |
| Beans, soy | 1215 | 721 |
| Beets | 1215 | 721 |
| Borax, fine | 1431 | 849 |
| Bran | 432 | 256 |
| Brick, common red | 3240 | 1922 |
| Brick, fire clay | 4050 | 2403 |
| Brick, silica | 3455 | 2050 |
| Brick, chrome | 4725 | 2803 |
| Brick, magnesia | 4320 | 2563 |
| Buckwheat | 1107 | 657 |
| Cardboard | 1161 | 689 |
| Cement - clinker | 2174 | 1290 |
| Cement, Portland | 2538 | 1506 |
| Cement, mortar | 3644 | 2162 |
| Cement, slurry | 2431 | 1442 |
| Chalk, solid | 4212 | 2499 |
| Charcoal | 351 | 208 |
| Cinders, furnace | 1539 | 913 |
| Cinders, Coal, ash | 1080 | 641 |
| Clay, dry excavated | 1836 | 1089 |
| Clay, wet excavated | 3078 | 1826 |
| Clay, dry lump | 1809 | 1073 |
| Clay, fire | 2296 | 1362 |
| Clay, wet lump | 2700 | 1602 |
| Clay, compacted | 2943 | 1746 |
| Clover seed | 1296 | 769 |
| Coal, Anthracite, solid | 2538 | 1506 |
| Coal, Anthracite, broken | 1863 | 1105 |
| Coal, Bituminous, solid | 2269 | 1346 |
| Coal, Bituminous, broken | 1404 | 833 |
| Coconut, shredded | 593 | 352 |
| Coffee, fresh beans | 946 | 561 |
| Coffee, roast beans | 728 | 432 |
| Concrete, Asphalt | 3781 | 2243 |
| Concrete, Gravel | 4050 | 2403 |
| Concrete, Limestone/Portland | 3996 | 2371 |
| Copra, medium size | 892 | 529 |
| Copra, meal, ground | 1080 | 641 |

| | | |
|----------------------------|------|------|
| Cork, solid | 405 | 240 |
| Cork, ground | 270 | 160 |
| Corn, on the cob | 1215 | 721 |
| Corn, shelled | 1215 | 721 |
| Glass, Cullet | 2700 | 1602 |
| Grain, Culm | 1269 | 753 |
| Dolomite, solid | 4886 | 2899 |
| Earth, dry | 2105 | 1249 |
| Earth, moist | 2431 | 1442 |
| Earth, wet | 2700 | 1602 |
| Earth, dense | 3374 | 2002 |
| Earth, mud loose | 2916 | 1730 |
| Earth, packed | 2565 | 1522 |
| Fertilizer, acid phosphate | 1620 | 961 |
| Flaxseed, whole | 1215 | 721 |
| Flour, wheat | 1000 | 593 |
| Garbage/rubbish | 811 | 481 |
| Glass, window | 4347 | 2579 |
| Granite, solid | 4536 | 2691 |
| Granite, broken | 2781 | 1650 |
| Grain - Maize | 1281 | 760 |
| Grain - Barley | 1011 | 600 |
| Grain - Millet | 1281 | 760 |
| Grain - Wheat | 1315 | 780 |
| Gravel, loose, dry | 2565 | 1522 |
| Gravel, with sand, natural | 3240 | 1922 |
| 1/4-2" size gravel, dry | 2835 | 1682 |
| Gravel, wet 1/4 to 2 inch | 3374 | 2002 |
| Gypsum, solid | 4698 | 2787 |
| Gypsum, broken | 2174 | 1290 |
| Gypsum, crushed | 2700 | 1602 |
| Gypsum, pulverized | 1890 | 1121 |
| Halite (rock salt), broken | 2538 | 1506 |
| Ice, solid | 1549 | 919 |
| Ice, crushed | 1000 | 593 |
| Lignite, dry | 1350 | 801 |
| Lime, quick, lump | 1431 | 849 |
| Lime, quick, fine | 2024 | 1201 |
| Lime, stone, large | 4536 | 2691 |
| Lime, stone, lump | 2592 | 1538 |
| Lime, hydrated | 811 | 481 |
| Lime, wet or mortar | 2596 | 1540 |
| Limestone, solid | 4401 | 2611 |
| Limestone, broken | 2619 | 1554 |
| Limestone, pulverized | 2350 | 1394 |
| Linseed, whole | 1269 | 753 |

| | | |
|-----------------------------|-------|------|
| Malt | 566 | 336 |
| Manure | 674 | 400 |
| Marble, solid | 4320 | 2563 |
| Marble, broken | 2646 | 1570 |
| Mica, solid | 4859 | 2883 |
| Mica, broken | 2700 | 1602 |
| Mica - flake | 876 | 520 |
| Mortar, wet | 4050 | 2403 |
| Nickel silver | 14229 | 8442 |
| Oats | 728 | 432 |
| Oats, rolled | 512 | 304 |
| shells, ground | 1431 | 849 |
| Paper, | 2024 | 1201 |
| Peanuts, shelled | 1080 | 641 |
| Peanuts, not shelled | 458 | 272 |
| Peat, dry | 674 | 400 |
| Peat, moist | 1350 | 801 |
| Peat, wet | 1890 | 1121 |
| Pitch | 1943 | 1153 |
| Plaster | 1431 | 849 |
| Potatoes, white | 1296 | 769 |
| Pumice, stone | 1080 | 641 |
| Rubber, caoutchouc | 1593 | 945 |
| Rubber, manufactured | 2565 | 1522 |
| Rubber, ground scrap | 811 | 481 |
| Rye | 1188 | 705 |
| Salt peter | 2024 | 1201 |
| Sand, wet | 3240 | 1922 |
| Sand, wet, packed | 3509 | 2082 |
| Sand, dry | 2700 | 1602 |
| Sand, packed | 2835 | 1682 |
| Sand, water filled | 3240 | 1922 |
| Sand with stone/gravel, dry | 2781 | 1650 |
| Wet Sand with Gravel, wet | 3405 | 2020 |
| Sandstone, solid | 3916 | 2323 |
| Sandstone, broken | 2309 | 1370 |
| Sawdust | 354 | 210 |
| Shale, solid | 4509 | 2675 |
| Shale, broken | 2673 | 1586 |
| Slate, solid | 4536 | 2691 |
| Slate, broken | 2174 | 1290 |
| Slate, pulverized | 2296 | 1362 |
| Snow | 811 | 481 |
| Soda Ash, heavy | 1820 | 1080 |
| Soda Ash, light | 728 | 432 |
| Rocks/Stones | 4239 | 2515 |

| | | |
|-------------------|------|------|
| Tar | 1943 | 1153 |
| Trap rock, solid | 4859 | 2883 |
| Trap rock, broken | 2943 | 1746 |
| Turf | 674 | 400 |
| Dry Black Walnuts | 1027 | 609 |
| Wheat | 1296 | 769 |
| Wheat, cracked | 1134 | 673 |
| Wool | 2215 | 1314 |
| Wool | 82 | 1314 |

| Wood ² | (lbs./yd ³) | (kg./m ³) |
|-----------------------|-------------------------|-----------------------|
| | Apple | 1112 |
| Ash, black | 910 | 540 |
| Ash, white | 1129 | 670 |
| Aspen | 708 | 420 |
| Balsa | 287 | 170 |
| Bamboo | 506 | 300 |
| Birch (British) | 1129 | 670 |
| Cedar, red | 641 | 380 |
| Cypress | 860 | 510 |
| Douglas Fir | 893 | 530 |
| Ebony | 1618 | 960 |
| Elm (Wych) | 1163 | 690 |
| Elm (Rock) | 1374 | 815 |
| Iroko | 1104 | 655 |
| Larch | 994 | 590 |
| Lignum Vitae | 2158 | 1280 |
| Mahogany (Honduras) | 919 | 545 |
| Maple | 1273 | 755 |
| Oak | 994 | 590 |
| Oak (Red) | 1188 | 705 |
| Pine (Oregon) | 893 | 530 |
| Pine (Canadian) | 590 | 350 |
| Pine (Red) | 624 | 370 |
| Redwood (American) | 758 | 450 |
| Spruce (Canadian) | 758 | 450 |
| Spruce (Sitka) | 758 | 450 |
| Sycamore | 994 | 590 |
| Teak | 1112 | 660 |
| Willow | 708 | 420 |
| Pecan wood | 1269 | 753 |
| Bark, wood refuse | 405 | 240 |
| Cottonwood | 701 | 416 |

© Simetric.co.uk. (2010, July 15). Density of Materials-Material or Alloy. Retrieved from https://www.simetric.co.uk/si_metals.htm, (°) Simetric.co.uk. (2016, February 24). Density of Materials-Wood. Retrieved from https://www.simetric.co.uk/si_wood.htm

REPLACEMENT PARTS

We have built your vehicle to the highest standards using quality parts. Contact your local dealer for information about replacement parts by directly reaching out to us.




SCAN THIS CODE

to locate a dealer or visit us at
switchngo.com/locator


Contact us toll-free at (888) 311-0867

E-SERIES HOIST SYSTEM PARTS





| ITEM | Part Number | Description |
|------|---------------|---|
| 1 | 3210132-1 | 15K Electric Winch Assembly |
| 2 | 1600000 | 1/2" Cable (25') w/ Swivel Hook |
| 3 | 1820003 | Poly Glide Pad |
| 4 | 1830109-01 | Glide Pad Hold Down Screw |
| 5 | 1830110-01 | Glide Pad Hold Down Nut |
| 6 | 4600007 | Cable V-Roller Assembly |
| 7 | 4600006 | Yellow Rear Roller Assembly |
| 8 A | 1810013 | SR4016 Hydraulic Cylinder |
| 8 B | 1810014 | SR4020 Hydraulic Cylinder |
| 8 C | 1810015 | SR5020 Hydraulic Cylinder |
| 9 | 4870008 | Hydraulic Hose w/ Fittings |
| 10 | 3790000 | Electrical Junction Box |
| 11 | 4600013 | Hydraulic Pump w/ Tank and Wiring Harness |
| 12 | 2720121 | Cover for Hydraulic Pump |
| 13 | 2720120 | Mounting Plate for Hydraulic Pump |
| 14 | 3790002 | Electrical Plug for Control Pendant |
| 15 | 3790033 | Winch Stop Switch |
| 16 | 2720296 | Mounting Bracket for Winch Stop Switch |
| 17 | 1830117-01 | Body Lock Safety Pin |
| 18 | 2720127-08 | Mounting Bracket, Universal Rear |
| 19 | 2720217-03/04 | Mounting Bracket, Universal Front |
| 20 | 2720129 | Installation Spacer Tool |
| 21 | 1830124-01 | Flanged Bolt for Mounting Bracket |
| 22 | 1830125 | Serrated Flanged Nut for Mounting Bracket |

H-SERIES HOIST SYSTEM PARTS



| ITEM | Part Number | Description |
|------|---------------|---|
| 1 A | 3210136 | 15K Hydraulic Winch Assembly |
| 1 B | 3210138 | 18K Hydraulic Winch Assembly |
| 2 | 1600000 | 1/2" Cable (25') w/ Swivel Hook |
| 3 | 1820003 | Poly Glide Pad |
| 4 | 1830109-01 | Glide Pad Hold Down Screw |
| 5 | 1830110-01 | Glide Pad Hold Down Nut |
| 6 | 4600007 | Cable V-Roller Assembly |
| 7 | 4600006 | Yellow Rear Roller Assembly |
| 8 A | 1810013 | SR4016 Hydraulic Cylinder |
| 8 B | 1810014 | SR4020 Hydraulic Cylinder |
| 8 C | 1810015 | SR5020 Hydraulic Cylinder |
| 9 | 4870008-1 | Hydraulic Hose w/ Fittings |
| 10 | 3790000 | Electrical Junction Box |
| 11 | 3180155 | Hydraulic Manifold w/ Wiring Harness |
| 12 | 2720121 | Cover for Hydraulic Manifold |
| 13 | 2720120 | Mounting Plate for Hydraulic Manifold |
| 14 | 3790002 | Electrical Plug for Control Pendant |
| 15 | 3790033 | Winch Stop Switch |
| 16 | 2720296 | Mounting Bracket for Winch Stop Switch |
| 17 | 1830117-01 | Body Lock Safety Pin |
| 18 | 2720127-08 | Mounting Bracket, Universal Rear |
| 19 | 2720217-03/04 | Mounting Bracket, Universal Front |
| 20 | 2720129 | Installation Spacer Tool |
| 21 | 1830124-01 | Flanged Bolt for Mounting Bracket |
| 22 | 1830125 | Serrated Flanged Nut for Mounting Bracket |
| 23 | 1600013-01 | Vibration-Damping Clamp |
| 24 | 1830004-04 | Clamp Carriage Bolt |
| 25 | 1830114-01 | Clamp Nylock Nut |
| 26 | 487000X | Hydraulic Tube, Top Frame |
| 27 | 487000X | Hydraulic Tube, Upper Subframe |
| 28 | 4870003 | Hydraulic Hose w/ Fittings |



BODY PROP ROD WARNINGS & USE

Federal Regulation 29 CFR 1926.601, (b)(10) states “Trucks with dump bodies shall be equipped with positive means of support, permanently attached, and capable of being locked in position to prevent accidental lowering of the body while maintenance or inspection work is being done.” Accordingly, all hoist systems will include a body prop rod for a positive means of support. The purpose of the body prop rod is to provide a safety strut for supporting the hoist system when maintenance or repairs are performed. The body prop rod must be used when maintenance requires the hoist to be in a raised position. The body prop rod is for use only when the truck body is empty or removed. Ensure to read all the warning, caution, and danger labels before operating your hoist system.

DANGER

The body prop rod is only to be used to prop an unloaded body or an empty hoist system itself. Serious injury or death may occur if the body prop rod is misused.

WARNING



Do not place arms, hands, any part of the body, or objects between the Switch-N-Go® hoist system's top frame and subframe without the body prop rod engaged.

CAUTION

Do not power the winch system while the body is on the body prop rod.

OPERATE THE BODY PROP ROD

- Step 1—** Using the control pendant, raise the hoist system "UP" halfway to approximately 25° angle which reveals about 8" of the cylinder stroke, sufficient height to engage the prop rod.
- Step 2—** Rotate the prop rod counterclockwise until it is in a vertical position.
- Step 3—** Engage body prop rod by lowering it into the pocket.
- Step 4—** Lower the hoist system "DOWN" until the upper lift tube is nestled in the prop rod cup.
- Step 5—** Disconnect any power to the control pendant and vehicle so that the hoist system is not operated accidentally.
- Step 6—** To lower or disengage the body prop rod, operate this procedure in reverse.





SYSTEM MAINTENANCE

Routinely maintain your hoist system and winch by observing the weekly, monthly, and yearly checklists. All hoist systems generally require very little periodic maintenance, but there are a few actions that should be taken to ensure that it is always in top working condition.

WEEKLY

- Inspect the winch cable for visible damage such as kinks, knots, mashed or frayed portions and broken strands every time the winch is operated. If the winch cable is damaged, replace before it breaks under load as this could result in serious injury or damage. Follow replacement procedure on page 46.
- Inspect the winch brake for slippage or cable drifting on a regular basis by visually observing the winch brake while operating the winch under load. If the winch drum continues to turn more than a 1/4 revolution in 15 minutes after the button is released, the brake may need to be replaced. Reference the Warn® brake service kit instructions for replacement procedure.

MONTHLY

- Inspect and regrease all scissor hoist grease fittings as shown in the grease fitting diagram on page 50. Apply rust-preventing lubrication to the following:
 - Front body locks
 - Yellow rear rollers
 - Body rear ground rollers and nose rollers
 - Electrical connections
 - All moving parts
- Lubricate the winch cable per Lubricate Your Winch Cable instructions on page 51.
- Inspect all rollers and roller shafts for excessive wear or fractures. Replace any parts or components that are damaged, broken, or working improperly. Reference the spare parts diagram on page 38-41 or contact your local dealer for more information.



- Check hydraulic fluid levels. If fluid is needed, follow the procedure on page 50-51.
- Inspect all bolts, nuts, and rollers on the hoist system. Ensure they are tightened to the proper torque. See reference chart on page 54. Replace any damaged, broken bolts, or fasteners with grade 5 or better.
- Inspect hydraulic fittings and hoses for cracks or damage.
- Inspect all electrical wiring on the hoist system and accessories for damage by checking lights and controls are in proper working order.

YEARLY


- Replace the hoist system's hydraulic fluid, referencing the procedure found on pages 48-49.
- Fully inspect the vehicle chassis and Switch-N-Go® hoist system frame for cracks, deformation, or excessive wear. If the system or vehicle shows signs of damage, refer to the Troubleshooting section or contact your local dealer for more information.



WINCH CABLE REPLACEMENT

This winch cable replacement is for Warn® 15,000lbs or 18,000lbs winches.

The cable feeds out from the topside of the Switch-N-Go® hoist systems' winch



⚠ WARNING

Always maintain a minimum of five wraps of the cable on the drum while operating the winch. Failure to do so may result in the cable to pull free of the winch drum and drop the load.

WINCH CABLE INSTALLATION

- Step 1—** With the hoist system in the full-lowered position, wind the winch "OUT" until the cable is no longer wrapped around the winch drum.
- Step 2—** With an Allen wrench, loosen or remove the set screw holding the end of the cable in the winch drum. This is located on the passenger side of the winch drum.
- Step 3—** Remove and discard the old winch cable.
- Step 4—** Wrap a 1" piece of masking tape around the end of the NEW wire winch cable to prevent fraying during installation.
- Step 5—** Insert the taped wire cable into the cable anchor hole located on the passenger side of winch drum. Tighten the set screw with an Allen wrench and torque to 12-15 ft-lbs. Ensure you do not over-tighten the set screw as this may result in a stripped or damaged screw.
- Step 6—** Wind the winch "IN", coiling the wire cable as it feeds onto the winch drum. Add slight tension to the cable by holding the end with protective gloves. The coil must always maintain a minimum of 5 wraps on winch drum.
- Step 7—** Clean any excessive lubrication with a dry cloth from hoist system/ vehicle components once cable is fully coiled around the winch drum.






HOIST SYSTEM HYDRAULIC FLUID CHANGE

E-series Hydraulic Fluid Capacities

| | Hoist Model | Reservoir Tank (Quarts) | Approximate System Oil Capacity (Quarts) |
|----------|-------------|-------------------------|--|
| E-SERIES | 4016 | 3.5 | 4.5 |
| | 4020 | 3.5 | 6 |
| | 5020 | 3.5 | 9 |

E-series



H-series Hydraulic Fluid Capacities

| | Hoist Model | Reservoir Tank (Gallons) | Approximately System Oil Capacity (Gallons) |
|----------|-------------|--------------------------|---|
| H-SERIES | 4016 | 15-20 | 1 + vehicle's tank capacity |
| | 4020 | 15-20 | 1.5 + vehicle's tank capacity |
| | 5020 | 15-20 | 2.25 + vehicle's tank capacity |

WARNING

When performing maintenance on the hoist in the raised position, ensure the truck body is removed, and that the body prop rod is securely in place.

- Step 1—** This procedure requires there be no truck body on the hoist. Unload the body by following the procedures on pages 29-31 of this manual.
- Step 2—** Stow away the body prop rod and lower the hoist all the way down flat.
- Step 3—** Remove breather cap on hydraulic reservoir tank.
- Step 4—** Using a siphon pump, remove all the old fluid from the hydraulic tank.
- Step 5—** Completely fill the hydraulic tank with hydraulic oil equivalent to Grade 32 (such as ATF-Dextron II or Mobile DTE 13).
- Step 6—** Raise the hoist "UP" halfway to approximately 25° angle which reveals about 8" of the cylinder stroke.
- Step 7—** Rotate the prop rod counterclockwise until it is in a vertical position and engage it by lowering it into the pocket.
- Step 8—** Lower the hoist "DOWN" until the upper lift tube is nestled in the prop rod cup.
- Step 9—** Continue to fill the Hydraulic reservoir leaving 1/2" void from the top of the reservoir. Carefully loosen the feed line on the hydraulic hoist cylinder, until a small amount of hydraulic oil weeps out, removing any trapped air pockets.
- Step 10—** Ensure all feed and return lines are tight and not leaking.
- Step 11—** Cycle the hoist system "UP" and "DOWN" and continue filling the reservoir tank leaving 1/2" from the top.
- Step 12—** Replace and tighten the breather cap on the reservoir tank.
- Step 13—** Lift the hoist "UP", disengage the prop rod and continue to lower the hoist "DOWN", checking the operation.




LUBRICATING THE HOIST SYSTEM & BODIES

Lubrication is vital to preventing premature wear as this may result in hoist system malfunction or system failure

- Lubricate all grease fittings as shown below with run-out or marine grease.
 - (3) Grease fittings are located on the lower shaft scissor hoist connected to the bottom hoist frame.
 - (2) grease fittings are located on the top frame and bottom of the middle section of the scissor hoist
 - (2) Grease fittings are located on the upper shaft scissor hoist connected to the top hoist frame

All Switch-N-Go® truck bodies' moving parts are equipped with grease fittings and should be lubricated according to the System Maintenance schedule. Specifically make sure body nose rollers and rear ground rollers stay lubricated.

GREASE FITTING DIAGRAM





LUBRICATING THE WINCH CABLE

⚠ NOTICE

The surface of the cable may become covered with dirt, rock dust or other material during their operation. Be sure to clean the cables before applying lubrication to ensure proper penetration.

The lubricant you apply should be light bodied enough to penetrate to the cable's core. You can normally apply lubricant by dripping it on the cable, spraying it on, or brushing it on. In all cases, you should apply it at a place where the cable is bending, such as around a sheave to more easily penetrate the cables's core.

⚠ NOTICE

Never apply heavy grease to the cable because it can trap excessive grit, which can damage it. Nor should you apply used "engine oil" because it contains materials that can damage the cable.



SYSTEM TEST & PRE-OPERATION CHECKLIST

Failure to properly test and check the system may result in premature wear, improper functionality, or a system failure.

- Ensure you have been properly instructed how to operate the Switch-N-Go® upfitted vehicle.
- Ensure you have been instructed how to connect the control pendant into the proper receptacle(s) or power on and off the wireless control pendant.
- Ensure you have been instructed how to load and unload truck bodies using the hoist system both empty and loaded.
- Ensure you are aware of the GVWR, TUVW, hoist system weight, load capacities of the hoist system and the vehicle. Information is located on the vehicle's driver inside pillars or inside the door panel.
- Check all nuts and bolts are properly torqued, using the torque chart on shown on page 54.
- Check to make sure all electrical connections and wires are tight and free from all pinching or cutting hazards, as this may lead to malfunctions or damage.
- Check to make sure the body prop rod is safely installed and is working properly.
- Check all grease fittings are lubricated with either run-out or marine grease.
- Check the winch cable is fastened tightly and spools evenly around the drum.
- Ensure the winch cable has minimum of 5 spools around the drum remaining when fully extended.

- When retracting the winch cable, ensure it spools evenly around the winch drum
- Check that the batteries and fuses are connected and are working properly.
- Check that all hydraulic fittings are free of leaks. When checking for leaks please wear protective eye wear and gloves to protect face and hands from high pressure leaks.
- Check all high pressure hoses that are connected to the hoist, vehicle, and/or hydraulic system.
- Test that the control pendant functions are working properly.
- Test the system to its maximum operating dump angle by pressing the button marked "UP" on the control pendant to raise it up to 50°. Then press "DOWN" to return the hoist the horizontal position.


TORQUE TABLE

| Size | Grade 2 | | Grade 5 | | Grade 8 | | 18-8 S/S | |
|-------|---------|------|---------|------|---------|------|----------|------|
| | Coarse | Fine | Coarse | Fine | Coarse | Fine | Coarse | Fine |
| #4* | — | — | — | — | — | — | 5.2 | — |
| #6* | — | — | — | — | — | — | 9.6 | — |
| #8* | — | — | — | — | — | — | 19.8 | — |
| #10* | — | — | — | — | — | — | 22.8 | 31.7 |
| 1/4" | 4 | 4.7 | 6.3 | 7.3 | 9 | 10 | 6.3 | 7.8 |
| 5/16" | 8 | 9 | 13 | 14 | 18 | 20 | 11 | 11.8 |
| 3/8" | 15 | 17 | 23 | 26 | 33 | 37 | 20 | 22 |
| 7/16" | 24 | 27 | 37 | 41 | 52 | 58 | 31 | 33 |
| 1/2" | 37 | 41 | 57 | 64 | 80 | 90 | 43 | 45 |
| 9/16" | 53 | 59 | 82 | 91 | 115 | 129 | 57 | 63 |
| 5/8" | 73 | 83 | 112 | 128 | 159 | 180 | 93 | 104 |
| 3/4" | 125 | 138 | 200 | 223 | 282 | 315 | 128 | 124 |
| 7/8" | 129 | 144 | 322 | 355 | 454 | 501 | 194 | 193 |
| 1" | 188 | 210 | 483 | 541 | 682 | 764 | 287 | 289 |

*Size from 4-10 are in lb-in
Size from 1/4 up are lb-ft


†Fine thread figures are 1-14
Grade 2, 5 & 8 values are plated bolts

CONTROL PENDANT PIN-OUT DIAGRAM






SYSTEM DIAGRAM {E-SERIES}



SYSTEM DIAGRAM {H-SERIES}





TROUBLESHOOT

If you're having issues with your hoist system, use our interactive troubleshoot guide at the link below.



SCAN THIS CODE

to troubleshoot your hoist system or visit us at switchngo.com/troubleshoot

E-series | Electric over hydraulic system

| Behavior of Problem | Cause of Problem | Solution (Instructions or see reference) |
|---|---|--|
| Neither winch nor hoist will respond or is weak | Control pendant disconnected or defective | Disconnect and reconnect control pendant Check pendant plug to make sure all (5) pins are not bent, broken, or pushed back |
| | 12V DC power disconnected | Check all power and ground terminal connections Check for and replace blown fuse (600A) Check wire harness connections at junction box |
| | Weak vehicle batteries | Test vehicle batteries with voltmeter and replace if needed Ensure vehicle battery requirements are satisfied |

| Behavior of Problem | Cause of Problem | Solution (Instructions or see reference) |
|---|---|--|
| Hoist will not raise or lower | Bad ground wire connection | Check ground connections at vehicle battery, hoist junction box, winch, pump motor, and hoist frame to chassis |
| | Defective coil (black-box coil, qty 2) | Swap with other coil to determine which one may be defective Replace defective coil |
| | Body prop rod is engaged or is in the "UP" position | Disengage body prop rod and return to the "DOWN" position |
| | Foreign obstruction between top frame and subframe of the hoist system. | Remove any tools, wires, hoses, or other foreign objects from the hoist system |
| Weak/no hoist operation | Pump motor not functioning | Replace Bucher pump motor or hydraulic pump assembly |
| Winch will not move in either direction | Vehicle battery(s) disconnected | Check 600A fuse Replace fuse if blown Reconnect vehicle battery |
| | Defective Warn relay block | Replace Warn relay block |
| | Malfunctioning stop switch (Winch will not winch in) | Check wiring to stop switch Replace winch stop switch assembly |
| | Warn winch motor is defective | Replace Warn winch motor |
| Winch spools out under load | Winch brake clutch slipping | Replace brake clutch in winch |
| | Winch gears damaged | Contact your dealer |
| Hoist system is acting sporadically | Defective diodes in junction box | Use a multimeter to determine which diode is defective Replace defective diode(s) |
| Breather cap pops off hydraulic tank | Pump was dead headed Load too heavy Dirty fluid | Flush and replace fluid 3/4 full Do not over fill Replace breather cap |



H-series | Full hydraulic system

| Behavior of Problem | Cause of Problem | Solution (Instructions or see reference) |
|---|---|--|
| Neither winch nor hoist will respond or is weak | Control pendant disconnected or defective | Disconnect and reconnect control pendant. Check pendant plug to make sure all (5) pins are not bent, broken, or pushed back. |
| | 12V DC power disconnected | Check all power and ground terminal connections Check for and replace blown fuse (25A) Check wire harness connections at junction box |
| | Dirty hydraulic fluid | Check filters, flush and refill hydraulic fluid Remove valve, clean to ensure it is not plugged |
| Hoist will not raise or lower | Lack of hydraulic fluid flow | Check for leaks or clogged in-line filters Check for blockage in the Bucher valve manifold Fill the hydraulic tank with Grade 32 hydraulic fluid (such as ATF-Dextron II or Mobile DTE 13) |
| | Broken or cut hydraulic line | Repair leaks or dry-rot cracks in hydraulic lines |
| | Body prop rod is engaged or is in the "UP" position | Disengage body prop rod and return to the "DOWN" position |
| | Foreign obstruction between top frame and subframe of the hoist system. | Remove any tools, wires, hoses, or other foreign object from the hoist system |

| Behavior of Problem | Cause of Problem | Solution (Instructions or see reference) |
|---|---|--|
| Winch will not move in either direction | Battery(s) is disconnected | Check 25A fuse Replace fuse if blown Reconnect battery |
| | Malfunctioning stop switch (Winch will not winch in) | Check wiring to stop switch Replace winch stop switch assembly |
| | Winch motor is defective | Replace the winch motor |
| Winch spools out under load | Winch brake clutch slipping | Replace brake clutch in winch |
| | Winch gears damaged | Contact your dealer |
| Hoist system is acting sporadically | Defective diodes in junction box | Use a multimeter to determine which diode is defective Replace defective diode(s) |
| | Loose junction box connection | Check/ Tighten power and ground connectors at junction box |

PROUDLY
MADE
SAEGERTOWN, PA

Deist[™]
INDUSTRIES, INC

switchngo.com • 888-311-0867
607 Erie Street Saegertown, PA 16433